

Tabulky příslušenství

Možnosti montáže šroubovacích elektrických topných jednotek řady TJ

Průměr nádoby [mm]	Typ	TJ 6/4" - 2*	TJ 6/4" - 2,5*	TJ 6/4" - 3,3	TJ 6/4" - 3,75*	TJ 6/4" - 4,5*	TJ 6/4" - 6*	TJ 6/4" - 7,5	TJ 6/4" - 7,5*	TJ 6/4" - 9	TJ 6/4" - 9*
500	OKCE 200 S	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 200 NTR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 200 NTRR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 200 NTRR/SOL	▲	▲	▲	▲	▲	-	-	-	-	-
	OKCE 250 S	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 250 NTR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 250 NTRR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 250 NTR/HP	▲	▲	▲	-	-	-	-	-	-	-
	OKC 250 NTRR/SOL	▲	▲	▲	▲	▲	-	-	-	-	-
550	OKC 300 NTRR/SOL	▲	▲	▲	▲	▲	-	-	-	-	-
	OKCE 300 S	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 300 NTR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 300 NTRR/BP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKC 300 NTR/HP	▲	▲	▲	▲	▲	-	-	-	-	-
	OKCE 400 S	▲	▲	▲	▲	▲	▲	-	-	-	-
	OKC 400 NTR/BP	▲	▲	▲	▲	▲	▲	-	-	-	-
600	OKC 400 NTRR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 400 NTR/HP	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 400 NTRR/HP/SOL	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKCE 500 S	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 500 NTR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 500 NTRR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	-
750	OKC 500 NTR/HP	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 500 NTRR/HP/SOL	▲	▲	▲	▲	▲	▲	▲	-	▲	-
	OKC 750 NTR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲
	OKC 750 NTRR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲
850	OKC 750 NTR/HP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲
	OKC 1000 NTR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲
	OKC 1000 NTRR/BP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲
	OKC 1000 NTR/HP	▲	▲	▲	▲	▲	▲	▲	-	▲	▲

* TJ 6/4" s prodlouženou chladnou částí

▲ lze montovat

- nelze montovat

Možnosti montáže přírubových elektrických topných jednotek řady R a SE

Průměr nádoby [mm]	Typ	REU 18-2,5	RDU 18-2,5	RDU 18-3	RDU 18-3,8	RDU 18-5	RDU 18-6	RDW 18-7,5	RDW 18-10	RSW 18-12	RSW 18-15	SE 377	SE 378
550	OKCE 300 S	●	●	●	●	●	●	●	●	●	-	-	-
	OKC 300 NTR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 300 NTRR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 300 NTR/HP	▲	▲	▲	▲	▲	▲	▲	▲	-	-	-	-
	OKCE 400 S	●	●	●	●	●	●	●	●	●	●	-	-
	OKC 400 NTR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 400 NTRR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 400 NTR/HP	▲	▲	▲	▲	▲	▲	▲	▲	-	-	-	-
	OKC 500 NTRR/SOL	●	●	●	●	●	●	●	●	-	-	-	-
600	OKC 400 NTR/HP	▲	▲	▲	▲	▲	▲	▲	▲	-	-	-	-
	OKCE 500 S	●	●	●	●	●	●	●	●	●	●	-	-
	OKC 500 NTR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 500 NTRR/BP	●	●	●	●	●	●	●	●	-	-	-	-
	OKC 500 NTR/HP	▲	▲	▲	▲	▲	▲	▲	▲	-	-	-	-
750	OKCE 750 S	■	■	■	■	■	■	■	■	■	■	▲	▲
	OKC 750 NTR/BP	■	■	■	■	■	■	■	■	■	■	▲	-
	OKC 750 NTRR/BP	■	■	■	■	■	■	■	■	■	■	▲	-
850	OKCE 1000 S	■	■	■	■	■	■	■	■	■	■	▲	▲
	OKC 1000 NTR/BP	■	■	■	■	■	■	■	■	■	■	▲	▲
	OKC 1000 NTRR/BP	■	■	■	■	■	■	■	■	■	■	▲	▲

▲ lze montovat

■ lze montovat jen s redukční přírubou 225/150

● lze montovat jen s redukční přírubou 210/150

- nelze montovat